

# WATER LEAK SENSOR

Undetected water can cause thousands of dollars in damage. Protect your home from potential water damage by keeping a Water Leak Detector anywhere flooding is a potential danger—near aquariums, sump pumps, plumbing, sinks, refrigerators, dishwashers, washing machines, water heaters, toilets, basement, and garages.

## INSTALLING THE BATTERY

Insert coin between top and bottom halves of case. Turn coin to separate. Connect 9-V battery to clip. Position battery inside compartment and then close the case.

## TESTING

Wet your finger and touch the two contacts, a loud alarm will sound. Alarm stops when two contacts keep dry.

## PLACEMENT


Place the Water Leak Sensor facing up, or on its right side with the metal sensing contacts down, otherwise it will not function properly with contacts up.

## FLOODING

A loud alarm will sound ceaselessly when the sensor is in contact with water. Alarm will sound until the battery runs out, or up to 72 hours.

## LOW VOLTAGE

A loud alarm will sound and LED light is activated intermittently when battery gets low.



1. Alarm
2. Sensing Contacts
3. Battery Access

## NOTES

Although the Water Leak Detector depletes battery only when alarm sounds, yearly battery replacement and retest of Leak Alarm is recommended for proper operation. Alarm will also sound when battery gets low.

## HELPFUL HINTS

Situation	Probable Causes	Solutions
False alarm sounds	Battery voltage is low	Change the battery
	You're using the Water Leak Sensor on a conductive surface (ie. Metal)	Place a piece of thin paper or plastic between Leak Alarm and metal surface
Unit does not sound alarm even when touching water	Metal contacts are up, not touching surface with water	Make sure metal contacts are down on surface where water is to be detected
	Battery is dead	Replace the battery

## SPECIFICATIONS

Manufacturer	Smarthome
Manufacturer Product No.	71631 - Smarthome Water Leak Sensor
UPC	813922012217
Dimensions (Approximate)	3 1/4" x 3 1/4" x 1 3/8"
Alarm	Loud > 95db, up to 72 hours
Power	Powered by 1 x 9V 6F22 battery (included). Sound and LED indication are activated when battery is low.
Smarthome Limited Warranty	Smarthome warrants to original consumer of this product for a period of 30 days from date of purchase, this product will be free from defects in material & workmanship & will perform in substantial conformity with its owner's manual. Warranty shall not apply to defects caused by misuse or neglect.

## Questions?

For additional information, refer to the Smarthome Water Leak Sensor webpage:  
[www.smarthome.com/71631.html](http://www.smarthome.com/71631.html)  
 Call our friendly tech support @ 1-800-SMARTHOME (800-762-7846)

**SMARTHOME™**